



Real Time GPS Vehicle Tracking Solutions

Call Today 888-880-0660

ST Sentinel Setup Instructions

1. Activation & Setup

Your ST Sentinel has been shipped to you activated and pre-programmed on your desired reporting rate. The battery is included and attached and there is no further assembly required. Thus, you are instantly ready to commence tracking your asset right out of the box.

2. Placement

Placement of the ST Sentinel is important to ensure accurate, reliable, and consistent GPS reporting. Place the device in the open air, where it is sure to have an unobstructed view up to the sky. It is vital that the device be able to easily communicate with the GPS satellites overhead, and this can be inhibited by structures such as metal, steel, and wood surfaces. The ST Sentinel GPS signal can generally penetrate through fiberglass, Plexiglas, plastic, vinyl, canvas, and materials of moderate density. Bear in mind that the ST Sentinel is capable of exposure to harsh conditions; it is both waterproof and weather resistant and designed to withstand a variety of extreme temperatures. It is acceptable to cover the device in order to protect/ conceal it, however it must be placed beneath one of the acceptable materials mentioned above.

3. Tracking

Once the ST Sentinel has been placed in the field, you should allow the device ample time to generate its first reports from the new location. To view the tracking info, go to www.worldtrackingsolutions.com and click on "My Site". Click on the thumbnail logo for the ST Sentinel and enter your assigned username and password when prompted (Note: username and password are included in the box the device was shipped in).

After logging in, select the radio button labeled "Today's Track" under the Map Type heading in the middle of the screen (Note: you can also modify the map to view any previous day's tracking by choosing "Select Track day/time" and the corresponding date). Once you have chosen the Map Type, click the "Show Me" button in the lower-right corner of the screen to see the map. The map will open in a separate window, so be sure your internet browser is configured to allow pop-ups from our website.

Tracking information is displayed on the map and in the data table below that map. Tracking information is stored on the server for up to 120 days back. Any information needed beyond this time should be exported and saved to your PC because it is permanently deleted after the 120 day window.